





Positie van de ophangstrippen
Positionnement des pattes de fixation
Laschen - anordnung
Position of hanging strips

Rad L	a	b	c	d	e
400	116	****	****	****	116
600	116	****	****	****	116
800	116	****	****	****	116
1000	116	****	****	****	116
1200	116	****	****	****	116
1400	116	****	****	****	116
1600	116	668	****	700	116
1800	116	768	****	800	116
2000	116	868	****	900	116
2200	116	968	****	1000	116
2400	116	734	700	734	116
2600	116	767	834	767	116
2800	116	867	834	867	116
3000	116	934	900	934	116

H	H1	H2
300	245	105
400	345	205
500	445	305
600	545	405
700	645	505
900	845	705



90.00.88.85



Head Office

The Radiator Centre, 7 Holywell Hill, St Albans, AL1 1EU

Tel: 01727 840344